

# FLYCASE PRO

QUICK REFERENCE GUIDE

GUIDE D'INSTALLATION RAPIDE

**PIKA  
ONE**



Copyright © 2004 PikaOne. All rights reserved.  
All product names stated are trademarks of their respective holders.  
Specifications are subjects to change without notice.

[www.pikaone.com](http://www.pikaone.com)

**PIKA  
ONE**

Before starting the installation procedure, refer to appendices, to learn about the limitations and possibilities that FireWire interface offer you.

Also refer to minimum requirements and check whether your whole system meets the required configurations.

## INSTALLATION

1. Start your computer.
2. Power up your FLYCASE PRO.
3. Connect your FLYCASE PRO to the computer.
4. Software installation.

### POWER UP YOUR FLYCASE PRO

You must always use the external power supply provided with your FLYCASE PRO and switch on your FLYCASE PRO.

### CONNECT YOUR FLYCASE PRO TO THE COMPUTER

Connect your FLYCASE PRO with one end of the cable provided, (FireWire 800, FireWire 400 or FireWire iLink/DV) and the other end of this cable with the appropriate port on your computer.

### SOFTWARE INSTALLATION

After a few seconds, the power led on your FLYCASE PRO will light up constant blue.

Your computer is now ready to detect your FLYCASE PRO. Finish installation by referring to the "software installation" chapter (page 9) in the user's manual supplied on the CD.

### OPERATIONG LEDS

Flashing red light indicates access to disk.  
Continuous blue light indicates power is ON.

For a complete information using your FLYCASE PRO, please refer to our USER 's GUIDE in the PikaOne CD.

#### PikaOne telephone support numbers

England 44 (0) 207 949 0192

Germany 49 (0) 696 698 4715

Spain 34 (0) 9 13 49 65 05

France 33 (0) 3 87 17 01 33

Italy 39 (0) 2 48 27 11 44

[www.pikaone.com](http://www.pikaone.com)

Avant de commencer la procédure d'installation, reportez-vous au manuel de l'utilisateur sur le CD fourni, afin de vous informer sur les spécificités des interfaces FireWire.

Vérifiez bien que votre système complet répond bien aux configurations minimum requises.

## INSTALLATION

1. Démarrage de votre ordinateur.
2. Mise sous tension du FLYCASE PRO.
3. Connexion à l'ordinateur du FLYCASE PRO.
4. Installation logicielle.

### MISE SOUS TENSION DE VOTRE FLYCASE PRO

Il faudra toujours connecter le boîtier d'alimentation externe livré avec votre FLYCASE PRO et le mettre sous tension.

### CONNEXION DU FLYCASE PRO À L'ORDINATEUR

Connectez une extrémité d'un des cables fournis, (FireWire 800, FireWire 400 ou FireWire iLink/DV) au FLYCASE PRO et l'autre extrémité du cable au port correspondant de votre ordinateur.

### INSTALLATION LOGICIELLE

Après quelques instants, le voyant alimentation de votre FLYCASE PRO s'allumera en bleu fixe.

Votre ordinateur est prêt à détecter votre FLYCASE PRO. Terminez l'installation en vous reportant au chapitre "installation logicielle" (page 9) du manuel d'installation fourni sur le CD.

### INDICATEURS DE FONCTIONNEMENT

En rouge clignotant indique un accès au disque.  
En bleu fixe, indique que l'alimentation est ON.

Pour connaître en détail l'ensemble des fonctions de votre FLYCASE PRO consultez le GUIDE D'INSTALLATION sur le CD PikaOne.

#### Support technique PikaOne

Angleterre 44 (0) 207 949 0192

Allemagne 49 (0) 696 698 4715

Espagne 34 (0) 9 13 49 65 05

France 33 (0) 3 87 17 01 33

Italie 39 (0) 2 48 27 11 44

[www.pikaone.com](http://www.pikaone.com)

FLYCASE PRO connection( FireWire 800) to MAC

Connexion (FireWire 800) du FLYCASE PRO à un MAC

