

FLYCASE

SILVER

EXTERNAL STORAGE PERIPHERALS



SILVER FLYCASE USB2

Up to 400 Gb storage

Aluminium case

Installs in seconds

Hot plug to any computer (Mac or PC)

Partition and format your drive using

the step-by-step software package provided

TECHNICAL SPECIFICATIONS

Capacities	40Gb - 80Gb - 120Gb - 160Gb - 200Gb - 250Gb - 300Gb - 400Gb
Transfer rate	USB2 up to 480 Mb/s USB1.1 up to 12 Mb/s
Dimensions	205 x 30 x 115 mm
Maximum power consumption	15 W
Adaptateur secteur	12 V/5V (15 W)
Weight	790 g



SYSTEM REQUIREMENTS

Mac or PC equipped as standard with USB2 or USB1.

- Mac OS 8.6 or higher
- Windows 98, 98SE, Windows ME, Windows 2000 or Windows XP
- Intel Pentium II / 350 MHz compatible processor or more powerful, 64MB RAM minimum for PCs.

PACKAGE CONTENTS

- 1 Cable USB 2 to USB 2-Host
- 1 Power supply adapter 12V/5V
- 1 CD with drivers and User's Guide



SILVER FLYCASE SLIM USB2

Up to 100 Gb storage

Aluminium case

Installs in seconds

Hot plug to any computer (Mac or PC)

Bus powered

Partition and format your drive using

the step-by-step software package provided

TECHNICAL SPECIFICATIONS

Capacities	20Gb - 40Gb - 60Gb - 80Gb - 100Gb
Transfer rate	USB2 up to 480 Mb/s USB1.1 up to 12 Mb/s
Dimensions	141 x 15,5 x 80 mm
Maximum power consumption	5 W
Bus powered	cable USB
Weight	200 g

SYSTEM REQUIREMENTS

Mac or PC equipped as standard with USB2 or USB1.

- Mac OS 8.6 or higher
- Windows 98, 98SE, Windows ME, Windows 2000 or Windows XP
- Intel Pentium II / 350 MHz compatible processor or more powerful, 64MB RAM minimum for PCs.

PACKAGE CONTENTS

- 1 Cable mini-USB 2 to USB 2-Host
- 1 USB power supply connector
- 1 CD with drivers and User's Guide